



- 0) Before Searching MI-12B, the Concrete Shielding Blocks will need to be checked.
- 1) "A" and "B" enter the MI-12B enclosure via MI-12 Service Building.
- 2) "A" and "B" proceed to Interlock box #1 and reset it.
- 3) "A" and "B" sweep the enclosure towards the target area.
- 4) "A" holds by the exit while while "B" uses the ladder to check on top of the Horn area and the Raw system.
- 5) "A" and "B" exit and reset Interlock Box #2.

Reviewed AD/RSO	Date
<i>Michael A. Gerardi</i>	4-1-09
Approved AD/OPS Dept. Head	Date
<i>[Signature]</i>	4-2-09